

Easy to install instructions.

1. Place 7/8" x 4" bar behind golf cart bag bar, placing bar 1/4" from edge of strap slot, hold in place and drill (2) 3/16" diameter holes using the support bar as a template.
2. Push eye bolt screws through drilled holes, add support washers and nuts, tighten nuts, cover threads with vinyl caps.
3. Place cart bag strap through handle on bag.

Installing the bag tray restrictor bar.

1. Drill 1/4" diameter hole on inside of bumper approximately 1" from top of bumper on center line of tray.
2. Drill 1/4" diameter hole into back of tray 1" below plastic plug.
3. Place rod into back tray hole until rod clears bumper, place rod with stop into the bumper.

